



REF	NUM. PARTE	NOMBRE	CANT
1	SK7000	MARCO SKI	1
2	SAK7050	TIMON AJUSTABLE SAK	1
3	SBK7020	ZAPATA	1
4	SK7010	PATA	1
5	SK7020	PERNO ENGANCHE SKI	2
6	SBK7060	PERNO DE TERCER PUNTO	1
7	SK1000	PERNO TERCER PUNTO SK1	1
8	SBK7030	PERNO DE TIMON	1
9	1010000	SEGURO RAPIDO	3
10	SK1010	SEGURO RAPIDO	1
11	SIN_NUM	TORNILLO DE 1/2" X 3-1/2"	1
12	SIN_NUM	RONDANA DE PRESION 1/2"	2
13	SIN_NUM	TUERCA DE 1/2"	2
14	SIN_NUM	TORNILLO DE 1/2" X 2"	1
15	SIN_NUM	SEGURO RAPIDO	1

